


72 Series Balances


5/8" TUBE BALANCE

Tube diameter 9/16" but considered 5/8" in the trade.



Balance Carrier

See page 44



Ordering Information

- 1) Measure metal tube length (Do not include nylon bearing).
- 2) Measure spiral rod length (Make sure rod is flush with screw hole end of tube before measuring).
- 3) Identify the color of the bearing (e.g., white, red or blue) and select our corresponding part number from the chart below.
- 4) To identify the appropriate carrier or shoe to be attached and other related accessories.

Note: Attached carriers and related accessories must be ordered separately.

Standard Rod

Tube Length	Rod Length	White Bearing	Red Bearing
10"	11-5/8"	72-P10SW	---
11"	12-5/8"	72-P11SW	---
12"	13-5/8"	72-P12SW	72-P12SR
13"	14-5/8"	72-P13SW	72-P13SR
14"	15-5/8"	72-P14SW	72-P14SR
15"	16-5/8"	72-P15SW	72-P15SR
16"	17-5/8"	72-P16SW	72-P16SR
17"	18-5/8"	72-P17SW	72-P17SR
18"	19-5/8"	72-P18SW	72-P18SR
19"	20-5/8"	72-P19SW	72-P19SR
20"	21-5/8"	72-P20SW	72-P20SR
21"	22-5/8"	72-P21SW	72-P21SR
22"	23-5/8"	72-P22SW	72-P22SR
23"	24-5/8"	72-P23SW	72-P23SR
24"	25-5/8"	72-P24SW	72-P24SR
25"	26-5/8"	72-P25SW	72-P25SR
26"	27-5/8"	72-P26SW	72-P26SR
27"	28-5/8"	72-P27SW	72-P27SR
28"	29-5/8"	72-P28SW	72-P28SR
29"	30-5/8"	72-P29SW	72-P29SR
30"	31-5/8"	72-P30SW	72-P30SR
31"	32-5/8"	72-P31SW	72-P31SR
32"	33-5/8"	72-P32SW	72-P32SR
33"	34-5/8"	72-P33SW	72-P33SR
34"	35-5/8"	72-P34SW	72-P34SR
35"	36-5/8"	72-P35SW	72-P35SR
36"	37-5/8"	72-P36SW	72-P36SR
37"	38-5/8"	72-P37SW	72-P37SR
38"	39-5/8"	72-P38SW	72-P38SR
39"	40-5/8"	72-P39SW	72-P39SR
40"	41-5/8"	72-P40SW	72-P40SR
41"	42-5/8"	72-P41SW	72-P41SR
42"	43-5/8"	72-P42SW	72-P42SR
43"	44-5/8"	72-P43SW	72-P43SR
44"	45-5/8"	72-P44SW	72-P44SR
45"	46-5/8"	72-P45SW	72-P45SR
46"	47-5/8"	72-P46SW	72-P46SR
47"	48-5/8"	72-P47SW	72-P47SR
48"	49-5/8"	72-P48SW	72-P48SR
49"	50-5/8"	72-P49SW	72-P49SR
50"	51-5/8"	72-P50SW	72-P50SR

Extended Rod

Tube Length	Rod Length	White Bearing	Red Bearing
10"	12-5/8"	72-P10RW	---
11"	13-5/8"	72-P11RW	---
12"	14-5/8"	72-P12RW	72-P12RR
13"	15-5/8"	72-P13RW	72-P13RR
14"	16-5/8"	72-P14RW	72-P14RR
15"	17-5/8"	72-P15RW	72-P15RR
16"	18-5/8"	72-P16RW	72-P16RR
17"	19-5/8"	72-P17RW	72-P17RR
18"	20-5/8"	72-P18RW	72-P18RR
19"	21-5/8"	72-P19RW	72-P19RR
20"	22-5/8"	72-P20RW	72-P20RR
21"	23-5/8"	72-P21RW	72-P21RR
22"	24-5/8"	72-P22RW	72-P22RR
23"	25-5/8"	72-P23RW	72-P23RR
24"	26-5/8"	72-P24RW	72-P24RR
25"	27-5/8"	72-P25RW	72-P25RR
26"	28-5/8"	72-P26RW	72-P26RR
27"	29-5/8"	72-P27RW	72-P27RR
28"	30-5/8"	72-P28RW	72-P28RR
29"	31-5/8"	72-P29RW	72-P29RR
30"	32-5/8"	72-P30RW	72-P30RR
31"	33-5/8"	72-P31RW	72-P31RR
32"	34-5/8"	72-P32RW	72-P32RR
33"	35-5/8"	72-P33RW	72-P33RR
34"	36-5/8"	72-P34RW	72-P34RR
35"	37-5/8"	72-P35RW	72-P35RR
36"	38-5/8"	72-P36RW	72-P36RR
37"	39-5/8"	72-P37RW	72-P37RR
38"	40-5/8"	72-P38RW	72-P38RR
39"	41-5/8"	72-P39RW	72-P39RR
40"	42-5/8"	72-P40RW	72-P40RR
41"	43-5/8"	72-P41RW	72-P41RR
42"	44-5/8"	72-P42RW	72-P42RR
43"	45-5/8"	72-P43RW	72-P43RR
44"	46-5/8"	72-P44RW	72-P44RR
45"	47-5/8"	72-P45RW	72-P45RR
46"	48-5/8"	72-P46RW	72-P46RR
47"	49-5/8"	72-P47RW	72-P47RR
48"	50-5/8"	72-P48RW	72-P48RR
49"	51-5/8"	72-P49RW	72-P49RR
50"	52-5/8"	72-P50RW	72-P50RR

An extra long extended rod is available with red bearings on the following sizes only:

Double Extended Rod

Tube Length	Rod Length	Part Number
15"	18-5/8"	72-P15RRR
19"	22-5/8"	72-P19RRR
21"	24-5/8"	72-P21RRR
23"	26-5/8"	72-P23RRR
27"	30-5/8"	72-P27RRR
33"	36-5/8"	72-P33RRR

Used Primarily by Keller

- The appropriate tensioning tools are 70-515 and 70-516.
- Many customers confuse this series with our 85 tilt series.
- 72 series always comes with a plastic guide attachment to the 2nd hole.

Note: Mostly "red bearings" are used for repairs. "Blue bearings" were not used on original windows but used when heavier glass was added. Blue bearing balances can be special ordered.